

MINERS WALL

See wiring instructions for

electrical assistance

 $(\underline{\pm})$ 

Please install the fixture onto a sufficiently strong, load bearing surface and only to be installed outside arms reach

If this product is being installed outdoors, or a location where the product will be exposed to high levels of moisture, you should apply a silicone seal around the back-plate/canopy.

